

HT Tracker Start Up Instructions

For iOS (Apple) version

Activation

1. Go to the Apple App store and search for “**HT Tracker**” and download the app.
2. Once loaded, push the “+” button on the upper right corner of the display. Once pushed, you will see the “**add sensor**” tab at the bottom of the page. Once you push the “**add sensor**” button, it will activate the pairing screen.
3. Pull the **plastic tab** from the HT Tracker sensor to activate the battery.
4. Place the HT Tracker sensor on the top of your phone with the large Oasis logo facing up. The side saying OH-31 needs to be facing down.
5. The screen will tell you when the sensor is synchronized with the app. Once synchronized, the app will start displaying the information generated by the sensor.
6. You will need to create a new login for the app with your email address and password.
7. Be sure to have the “**Update setting**” for “**iTunes and App Stores**” to “**green**”, so you get automatic app updates.
8. The app will then ask you questions about how you want to identify the use of the particular sensor. You can add as little information as the name of the sensor or fill out the other information if you wish. You can load up to 7 HT Tracker sensors on the app. Each HT Tracker has a unique electronic ID that the app will pick up. You just need to enter the information necessary so you know where each HT Tracker is located.
9. Once the HT Tracker app is operating, press the 3 lines in the upper left corner to open the page showing “**Temperature Units F or C**”. After you have selected the temperature units you can access the “**User Guide**” to learn your way around the app.